

PB - Separatori di fase T4-T5
PB - Phase barriers T4-T5
PB - Trennwände zwischen den Phasen T4-T5
PB - Sèparateurs de phase T4-T5
PB - Separadores de fase T4-T5







ABB SACE S.p.A.

Via Baioni, 35
24123 Bergamo Italy

Tel.: +39 035 395.111 - Telefax: +39 035 395.306-433

<http://www.abb.com>